



PIECE NO.	BASIC	BUTTON	SPIROL PIN	NUT	WARNING BAND	LOCK-WASHER	REMARKS
286706	288239	—	—	239357	—	—	—
286889	288239	290655	238379	238357	White	—	Cust I.D.
287046	288240	—	—	245335	—	242415	See View 2
287049	288239	290655	238379	239357	White	—	—
287130	288239	290655	238379	239357	White	—	Cust I.D.
287251	288241	291054	238379	239357	Yellow	—	Cust I.D.
287259	288242	—	—	245335	—	242415	See View 2
287280	288721	291624	238379	239357	White	—	Cust I.D.
287282	288241	291054	238379	239357	Yellow	—	—
288007	288241	—	—	—	—	—	Cust I.D.
288643	288644	—	—	239357	—	—	—
289120	288239	—	—	—	—	—	Cust I.D.
289997	288644	290655	238379	239357	White	—	Cust I.D.
101307	288721	290655	238379	239357	White	—	—
101396	101479	290655	238379	239357	White	—	Cust I.D.
101783	288644	291624	238379	239357	White	—	Cust I.D.
101849	101479	—	—	—	White	—	Cust I.D.
102191	102192	291054	238379	239357	Yellow	—	—



NUT
LOCKWASHER

PLACE THESE PARTS
IN POLYBAG AND ATTACH TO
VALVE



WARNING BAND -
VISIBLE WHEN IN RELEASED POSITION,
HIDDEN WHEN IN CHARGING POSITION.
YELLOW BAND INDICATES NON-INTER-
CHANGEABLE BUTTON.