













Bendix® Remanufactured Exchange Core Classes: Air Brake & Electronic Parts



Group 01: Compressors, Flange Mount				Group 1A: CAT® Flange Mount				Group 1B: Cummins® Flange Mount			Group 1C: DDC® Flange Mount															
 CLASS 26	 CLASS 14	 CLASS 05	 CLASS 06	 CLASS 1A	 CLASS 2A	 CLASS 1B	 CLASS 2B	 CLASS 1C	 CLASS 2C	 CLASS 1D	 CLASS 2D	 CLASS 1E	 CLASS 2E	 CLASS 1F	 CLASS 2F	 CLASS 1G	 CLASS 2G	 CLASS 1H	 CLASS 2H	 CLASS 60	 CLASS 2J, 3J	 CLASS 2K				
Group 1D: DDC Flange Mount		Group 1E: Cummins® Flange Mount		Group 1F: Mack® Flange Mount		Group 1G: Navistar® Flange Mount		1H: Volvo Flange Mount		Group 1I: Base Mount	Group 1J: DDC Flange Mount	Group 1K: CAT Flange Mount														
 CLASS 1D	 CLASS 2D	 CLASS 1E	 CLASS 2E	 CLASS 1F	 CLASS 2F	 CLASS 1G	 CLASS 2G	 CLASS 1H	 CLASS 2H	 CLASS 60	 CLASS 2J, 3J	 CLASS 2K														
Group 1L: DDC Flange Mount		Group 1M: DDC Flange Mount		Group 1N: Deere/ CAT Flange Mount		Group 1P: CAT Flange Mount		Group 1S: DDC Flange Mount		Group 1T: DDC Flange Mount		Group 1U: SAE B Flange Mount		Group 1V: Navistar Flange Mount		Group 1W: Navistar Flange Mount		Group 1X: Navistar Flange Mount		Group 1Y: Volvo Flange Mount		Group 12: Old-Style Base-Mount				
 CLASS 1L	 CLASS 1M	 CLASS 1N	 CLASS 1P	 CLASS 1S	 CLASS 1T	 CLASS 1U	 CLASS 1V	 CLASS 1W	 CLASS 1X	 CLASS 1Y	 CLASS 59	 CLASS 62	 CLASS 61													
Group 13: Old-Style Base-Mount														Group 14: CAT/DDC Flange Mount		Group 4		Group 6		Group 9	Group 9A	Group 9B	Group 9C	Group 9D	Group 26	
Engine-Lubed or Water-Cooled														Self-Lubed or Air-Cooled		 CLASS 37	 CLASS 13	 CLASS 66	 CLASS 17	 CLASS 68	 CLASS 29	 CLASS 79	 CLASS 96	 CLASS 9C	 CLASS 9D	 CLASS 63
 CLASS 02	 CLASS 01	 CLASS 30	 CLASS 56	 CLASS 57	 CLASS 55	 CLASS 64																				
Group 3		Group 5		Group 16: Dash Valves							Group 17: Limiting and Quick Release Valves					Group 25										
 CLASS 41	 CLASS 41	 CLASS 41	 CLASS 16	 CLASS 36	 CLASS 37	 CLASS 37	 CLASS 36	 CLASS 37	 CLASS 37	 CLASS 37	 CLASS 37	 CLASS 37	 CLASS 43	 CLASS 39	 CLASS 39	 CLASS 43	 CLASS 38	 CLASS 40	 CLASS 69	 CLASS 40						
Group 27		Group 28				Group 31			Group 32	Group 33	Group 34	Group 35	Group 36		Group 37		Group 38	Group 70	Group 73							
 CLASS 19	 CLASS 33	 CLASS 08	 CLASS 09	 CLASS 75	 CLASS 31	 CLASS 32	 CLASS 32	 CLASS 72	 CLASS 35	 CLASS 34	 CLASS 70	 CLASS 12	 CLASS 25	 CLASS 20	 CLASS 20	 CLASS 22	 CLASS 76	 CLASS 73	 CLASS 10							
Group SA	Group SC	Group SD	Group SE	Group SF	Group SG	Group SH	Group SK	Group SM	Group SN	Group SV	Group SW	Group SX	Group 90													
 CLASS F1	 CLASS F2	 CLASS F3	 CLASS G8	 CLASS G7	 CLASS F6	 CLASS F7 & F8	 CLASS E1	 CLASS F4	 CLASS F5	 CLASS E6	 CLASS E7	 CLASS E8	 CLASS J2	 CLASS J3 & J4												



For The Full-Size Wall Chart, Order BW1299

